



Bluetooth Keyboard User Manual

Product specifications

- | | |
|-------------------------------------|---|
| 1. Bluetooth 3.0 interface standard | 9. Standby Time : >100 days |
| 2. Operating Distance to 10 meters | 10. Charging Time : 3-4 hours |
| 3. Modulation system: GFSK | 11. Battery Capacity : 200 mA |
| 4. Operation Voltage: 3.0-4.2V | 12. Uninterrupted Working Time: 100 hours |
| 5. Operation current: <2.5mA | 13. Lithium Battery Life : 3 years |
| 6. Standby Current: <0.3mA | 14. Key Strength : 80+-10g |
| 7. Sleeping Current: <40uA | 15. Key life : 5million strokes |
| 8. Charging Current: >200mA | 16. Operating Temperature : -10-+55C |

Getting Started Guide

1. Button



Power toggle switch: slide switch ON or OFF to control the device power turn on or turn off.



Connect Button: Under the Power button turn on case, ready to connect to Ipad.

2. Indicator



Power

Power indicator: turn on the power toggle switch. The indicator light will be on for 4 seconds, then the light will go off.



Bluetooth connect indicator: Press on the [connect] button, the [Bluetooth] indicator light will be blinking, indicator light will stay on until the keyboard connect with your device.



Uppercase and lowercase indicator: Indicator light will stay on under the uppercase.



Charge

Charging indicator: indicator light will be on when the keyboard is charged by USB cable.

Charging

When the battery is low, the power indicator light flashes, that means need to charge the bluetooth keyboard.

1. Connect the B end of the original USB cable to the keyboard.
2. Connect the A end of the USB cable to the power adapter or A PC USB interface.
3. When charging charging "Charge" lights indicator will light up, when the battery is full "Charge" lights will automatically go out.

Bluetooth keyboard connection operation steps


1. To set the keyboard power button to "ON" position, the power indicator light will light up for 4 seconds, and then go out;



Press the "Connect" to connect a keyboard key, Bluetooth connection will twinkle lights when key Bluetooth is started, can be connected to or tablet the computer.



2. Open and unlock the tablet or computer, click on the flat Board computer "Settings" icon.



3. Select "bluetooth" in "Settings" interface, enter the bluetooth Settings interface, click on the bluetooth Pass to open the connection.

⚠ Caution:

1. In order to extend service life, we recommend you turn the keyboard off when there is long time no interaction.
2. We recommend to charge interaction when the [power] indicator light start blinking, it is time to recharge the keyboard. It's better not less than 3 hours when every time charging.


Spares Nordic AB
Fagerstagatan 7
163 53 Spånga, Sweden
CE FC ♻️ ♻️ ♻️ ♻️ ♻️



4. The tablet computer will automatically search enabled Bluetooth devices, wireless keyboard found signals, Click or the project link.



5. On the keyboard input displayed on the screen PIN pairing code, press the "Enter" key.



6. After completion of matching the status of the wireless keyboard will display a pairing.